


Relief Valves

Axelson®

Pilot-Operated Safety Relief Valves

Series H



- Full Flow Capacity
- Backflow Protection
- Simple Maintenance
- Non-Flowing Pilots
- Coated Bodies
- Easier Handling

In the mid 1940s, a new relief valve actuated with a pilot rather than a spring set a new standard for pressure control. The valve, manufactured over the years by companies like Garrett, USI and Axelson, is now manufactured and sold by NuFlo Measurement Systems under the Axelson brand.

NuFlo's Axelson® pilot-operated pressure relief valves are an example of a tradition of advanced design and high-quality manufacturing abilities. These valves offer advantages not found in other relief valves-spring- or pilot-operated.

The name Axelson has stood for ingenuity, quality and service for more than 100 years and NuFlo is committed to preserving that tradition for years to come.

Valve Types

Type HF

This is a full lift, pop-action valve with a fixed (5% to 7%) blowdown using a single non-flowing pilot. This type of valve is designed for gas and/or vapor service and is offered in sizes of 1" through 8" with operating pressures ranging from 20 psig to 6000 psig.

Type HL

This is a modulating valve with a fixed (3% to 5%) blowdown using a single non-flowing pilot. This valve is designed for gas, vapor and/or liquid service and is offered in sizes of 1" through 8" with operating pressures ranging from 15 psig to 1500 psig.

Advantages

Full Flow Capacity

In addition to the various API orifice sizes, NuFlo offers valves with non-standard API orifice sizes for maximum flow capacity. Many times this allows for the use of smaller size valves at a cost savings to the customer.

Backflow Protection

The unique NuFlo split piston (optional) is designed to eliminate the effect of pressure in the discharge system back-flowing into a relief valve on installations where several valves discharge into a common manifold.

Simple Maintenance

All maintenance, including changing the valve seat, can be performed using ordinary hand tools without removing the valve from the installation.

Non-Flowing Pilots

NuFlo non-flowing pilots reduce the problems of "freeze-up" caused by the pressure drop through the flowing-type pilots.

Coated Bodies

The bodies and piston housings of all NuFlo pilot-operated safety relief valves are internally and externally coated with Xylan® for corrosion protection and lubricity.

Easier Handling

A lifting eye is conveniently located on the center of the valve for ease of handling during installation or removal.

Features

Soft or Hard Seat Seals

Soft or hard seat seals are available for a variety of service conditions and applications. Soft seat seals are recommended for discharge set pressures of 25 psi to 1500 psi. Hard seat seals are recommended for discharge set pressures above 1500 psi.

Variable Flange Dimensions

Flange dimensions can be modified on special order to fit most existing installations. This permits NuFlo pilot-operated safety relief valves to be used as replacements for older spring-loaded valves which may not conform to new safety standards.

In-Service Test Kit

This optional feature allows checking or changing the pilot set pressure in the field with the valve in service.

Manual Blowdown

This optional device, which allows manual blowdown of the system, can also be controlled from a remote location.

Direct or Remote Control

Depending on the application, the operation of the NuFlo pilot-operated safety relief valve may be controlled directly from the point of installation or remotely.

No "Simmer"

NuFlo pilot-operated safety relief valves are designed to eliminate "simmer" at the valve seat. They do not require "percent accumulation" or over-pressure to operate.

Special Flanges

NuFlo pilot-operated safety relief valves can be supplied with special flanges such as Graylock, Taper-Lok, Lenz, etc.

Advantages and Features

Advantages and Features	NuFlo Pilot Operated		Competitive Spring Loaded Valve
	HF	HL	
Easy and economical to maintain All maintenance can be performed without removing valve from line	YES	YES	NO
Replaceable soft seat Saves costly lapping of valve seat	YES	YES	YES
Operates without simmer at valve seat Can be set close to system operating pressure. Unaffected by vibration of pulsation	YES	YES	NO
Block and bleed pilot as standard Reduces freeze-ups caused by pressure drop through flowing type pilots	YES	YES	NO
Accurate setting with small volume of pressure Test fixture available for fast accurate setting	YES	YES	NO
Backflow protection Prevents flow of gas back through valve when working on line	YES	YES	NO
Combines functions of blowdown and safety valves Saves cost of additional valves and piping	YES	YES	NO
Higher capacity per valve size	YES	YES	NO
Field test of pilot set pressure Set pressure can be checked or changed with valve still in service	NO	YES	NO
Can be used with solenoid valve For electric or pneumatic interface	YES	YES	NO
Coated internally and externally Bodies and piston housings. Xylan coated for corrosion protection and lubricity	YES	YES	NO
Balanced pilot Allows venting into discharge system without effect of back pressure	NO	YES	NO

Application

A pilot-operated pressure relief valve, according to the 1992 ASME Code Section VIII, Division 1, Section UG-126, is a pressure relief valve in which the major relieving device is combined with, and is controlled by, a self-actuated auxiliary pressure relief valve. NuFlo pilot-operated pressure relief valves are designed to be

used wherever there is a need to exhaust the overpressure volume of gas, vapor and/or liquid. Applications include oil and gas production systems, compressor stations, gas transmission (pipelines) facilities, storage systems, distribution systems and in all types of processing plants.

Valve Operation

NuFlo pilot-operated safety relief valves operate on the principle of unequal areas exposed to the same pressure. When the relief valve is closed, system pressure pushes upwards against the piston seat seal on an area equal to the inside diameter of the seat. Simultaneously, the same system pressure passes through the pilot, exerting a downward force on the piston acting on an area approximately 50% greater than the inside diameter of the seat. The resulting differential force holds the valve tightly closed. As the system pressure rises, the force against the piston seal

increases. Then, when the system pressure reaches the relief valve discharge set pressure, the pilot cuts off system pressure and opens the top of the piston to vent pressure. As the pressure above the piston is relieved, the relief valve opens, discharging line pressure.


When the predetermined blowdown pressure is reached, the pilot shuts off the exhaust and re-opens the flow of system pressure to the top of the piston, effectively closing the relief valve.

Operation Type HF

Relief Valve Closed


At below “set point”, the normally open combination pilot allows system pressure to enter the piston housing cavity of the relief valve on top of the free-floating piston. The top of the relief valve piston has a larger area than the valve seat where the piston seals. Equal pressure at both ends of the piston creates a differential downward force, which holds the piston tightly closed on the valve seat.

Below: Type HF relief valve (closed position)



Type HF Relief Valve


(Fixed Blowdown 5-7%)



Relief Valve Open

When system pressure reaches the set point, the pilot piston is lifted off the valve seat. The blowdown seat seals off incoming line pressure, causing the exhaust port to open and bleed pressure from the relief valve piston cavity. Decreasing pressure on the top of the relief valve piston allows the valve to open, relieving system overpressure. As system pressure drops below the blowdown reset point, the blowdown seat opens, reseating the pilot piston, which causes the exhaust port to close. System pressure re-enters the relief valve piston cavity, closing the relief valve.

Right: Type HF relief valve (relieving position)




Operation Type HL


Relief Valve Closed

At below "set point," the normally open Type HL pilot allows system pressure to enter the piston housing cavity of the relief valve on top of the free-floating piston. The top of the relief valve piston has a larger area than the valve seat where the piston seals. Equal pressure at both ends of the piston creates a differential downward force, which holds the piston tightly closed on the valve seat.

Below: Type HL relief valve (closed position)




Type HL Relief Valve



Relief Valve Open

When system pressure reaches the set point, the pilot piston forces the pilot stem upward by compressing the pilot valve spring. This movement of the stem simultaneously blocks the system pressure passageway through the pilot and commences the bleeding of pressure from the relief valve piston housing cavity. Decreasing pressure on the top of the relief valve piston allows system pressure to open, relieving system overpressure. As system pressure drops below the blowdown reset point, system pressure re-enters the relief valve piston cavity, closing the relief valve.

Right: Type HL relief valve (relieving position)



In-Service Testing and Pilot-Setting Options


All NuFlo pilot-operated pressure relief valves may be ordered with an In-Service Test Kit. The procedures for the use of this In-Service Kit are shown below.

Type HF In-Service Testing of Pilot Set Pressure

CAUTION: Never use oxygen as a pressure source.

Pressure from a cylinder of nitrogen or some other pressure source (NOT OXYGEN) may be used to check the setting or to reset the pressure at which the relief valve will operate.

1. Connect pressure hose from nitrogen bottle to field test valve "A".
2. Close vent valve "B".
3. Open field test valve "A".
4. Slowly open block valve "C" permitting test pressure to increase to valve set point.



5. Observe set pressure on test gauge and record.
6. Close valves "A" and "C".
7. Open vent valve "B".
8. Disconnect pressure hose from field test valve "A".

NOTE: For additional information on In-Service testing, refer to the service manual or technical data sheets for this product.

When a relief valve is not equipped with the In-Service Test Kit, a Relief and Blowdown test fixture can be used to check or change valve set and blowdown pressures in field shops. Only the pilots need to be removed from the relief valve and it is not necessary to remove the valve itself from the installation.


The operation of this portable test fixture is simple and convenient.

CAUTION: Never use oxygen as a pressure source.

Pressure from a cylinder of nitrogen or some other pressure source (NOT OXYGEN) may be used to check the setting or to reset the pressure at which the relief valve will operate.

Special training is not required and complete instructions are furnished with each fixture.


The test fixture may be ordered with optional needle valves and adapters for any type of pilot.



Type HL

Typical Direct Hook-Up with In-Service Test Valve (Gas Service Only)

1. Connect pressure hose from nitrogen bottle or hydraulic hand pump to test port of header block.
2. Close vent valve "A".
3. Slowly open block valve "B", or operate hydraulic hand pump, permitting test pressure to increase to valve set point.
4. Observe set pressure on test gauge and record.
5. Close valve "B", or release pressure on hand pump.
6. Open vent valve "A".
7. Disconnect pressure hose from test port.




NOTE: For additional information on In-Service testing, refer to the service manual or technical data sheets for this product.

Pilot Construction


The Type HF pilot is a single combination control with a fixed blowdown for controlling relief valve opening and closing pressure set points. The opening set pressure is determined by the force of a control spring, which holds the relief control section of the valve closed. When system pressure acting on the relief control valve seat area equals the spring force, the relief control opens, and the blowdown control section closes, blocking system pressure from passing into the chamber above the main valve piston. As the relief control opens, the pressure underneath the control seat is exposed to a larger pressure area which provides "snap" action of the control pilot to quickly reduce pressure in the piston dome. This pressure reduction causes the main valve piston to lift, relieving system pressure.

After the system pressure is reduced to a point whereby the control valve spring forces the blowdown control ball to unseat, the relief control valve closes, and the open blowdown control valve allows system pressure to re-enter the piston dome, forcing the main piston down to a closed valve position.



The Type HL pilot is a single-control pilot with a fixed blowdown for controlling the opening and closing of the relief valve. Opening and closing pressures are determined by the force of a pilot control spring. System pressure is applied to the pilot control piston and also to the pilot inlet "Hi" port. The lifting force produced by the pressure on the control piston is reacted by the opposing force of the pilot spring. When the spring force is greater than the pressure force of the control piston, system pressure is communicated through the inlet "Hi" port of the pilot to the top of the relief valve piston. Since the area on top of the relief valve piston is greater than the seat area, the valve is held in the closed position. As pressure increases above the set point, the force of the control piston becomes greater than the reacting spring force. This unbalanced condition shifts the pilot stem upward, blocking the pressure coming into the inlet "Hi" port and


allowing the pressure above the relief valve piston to bleed off. As the pressure force, (which holds the piston on the seat) decreases, the relief valve opens. If system pressure continues to rise, the piston lifts fully and remains open until system pressure is reduced sufficiently for the pilot spring to shift the pilot into its flowing position.




Function of the Split Piston

Normal Piston Position

All NuFlo pilot-operated pressure relief valves can be ordered with the exclusive NuFlo split piston. This piston is designed to eliminate the effect of back-pressure imposed on the discharge side of the valve.




Split Piston Separated



The split piston is recommended for installations where a manifold discharge system serves a number of relief valves. If a manifolded relief valve is out of service when one or more other valves exhausts into the common discharge system, the split piston separates and prevents backflow through the out-of-service valve.

Installation Schematics


Types HF



Type HL


Direct Hookup

Relief valves configured for direct operation are equipped with an internal pressure pickup tube (stinger) in the throat of the valve inlet. They are factory shipped as self-contained assemblies, ready for installation.



Remote Hookup

Relief valves configured for remote operation do not contain an integral pressure pickup connection. Pressure is sensed from a remote point on the vessel/process line through a single tube connected to the header block located on the valve.



Orifice Selection

Available Orifice Sizes for Type HF and HL Pilot-Operated Relief Valves

Valve Coefficient: 0.859 (gas), 0.674 (liquid)

Valve Size	Outlet	Orifice	Orifice Area (Sq. In.)	Valve Size	Outlet	Orifice	Orifice Area (Sq. In.)
1" X 2"	Single	D	0.110	3" x 4"	Single	J	1.287
		E	0.196			K	1.838
		F	0.307			L	2.853
		G	0.503			M	3.600
		GX	0.652			N	4.340
		1"	0.785			P	6.380
1-1/2" x 2"	Single	D	0.110	4" x 6"	Single/Dual	3"	7.068
		E	0.196			L	2.853
		F	0.307			M	3.600
		G	0.503			N	4.340
		H	0.785	P	6.380		
		J	1.287	4"	12.566		
		JX	1.633	6" x 8"	Single/Dual	Q	11.045
		1-1/2"	1.767			R	16.000
1-1/2" x 3"	Single	G	0.503	8" x 8"	Dual	T	26.000
		H	0.785			6"	28.270
		J	1.287			Q	11.045
		JX	1.633	R	16.000		
		1-1/2"	1.767	T	26.000		
2" x 3"	Single	G	0.503	8" x 10"	Single/Dual	7"	38.484
		H	0.785			7-1/2"	44.178
		J	1.287			Q	11.045
		JX	1.633			R	16.000
		K	1.838	T	26.000		
		KX	2.776	7"	38.484		
		2"	3.141	7-1/2"	44.178		

Trims Available (Materials of Construction)

	Standard		Stainless Steel		Full Stainless Steel		NACE	
	HF	HL	HF	HL	HF	HL	HF	HL
Body	CS (1)	CS (1)	CS (1)	CS (1)	SS (2)	SS (2)	CS (1)(3)	CS (1)(3)
Piston Housing	CS (1)	CS (1)	CS (1)	CS (1)	SS (2)	SS (2)	CS (1)(3)	CS (1)(3)
Piston	AL	AL	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS
Valve Seat	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS
Orifice	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS
Header Block	CS	316 SS	CS	316 SS	316 SS	316 SS	CS (3)	316 SS
Pilot Valve	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS	316 SS

NOTES: (1) A-216-Gr WCB (2) A-351-Gr-CF8M (3) HR_c 22 maximum

Soft Seat Service

Material	Continuous Temperature, °F		Minimum Pressure, psi		Maximum Pressure, psi	
	Max.	Min.	Pilot	Main	Pilot	Main
Buna-N	275	-65	15	15	6000	1500
Viton	400	-65	15	15	6000	1500
Teflon	400	-423	-	60	-	1500
Peek	480	-423	-	1500	-	3000
S.S.	-	-	-	1500	-	6000

Ordering Information

HF

1. Type of valve.
2. Inlet pipe size of valve.
3. Rating of inlet and outlet flanges: RF, RTJ or other.
4. Type of seal (hard or soft).
5. Set pressure (pressure at which valve will open).
6. Manual blowdown valve (optional).
7. In-service test unit (optional).
8. Construction and trim (unless otherwise specified, standard construction and trim will be furnished).
9. Characteristics of gas being controlled.
10. Specific gravity or molecular weight of gas.
11. Temperature of gas.
12. Back pressure (pressure on outlet).
13. Specify any special markings or identification.

HL

1. Type of valve (gas or liquid service).
2. Inlet pipe size of valve.
3. Rating of inlet and outlet flanges: RF, RTJ or other.
4. Type of seal (hard or soft).
5. Set pressure (pressure at which valve will open).
6. Manual blowdown valve (optional).
7. In-service test unit (optional).
8. Construction and trim (unless otherwise specified, standard construction and trim will be furnished).
9. Characteristics of gas and/or chemical components of products in system being controlled.
10. Specific gravity or molecular weight of gas and/or liquids.
11. Operating temperature of product.
12. Back pressure (pressure on outlet), if any.
13. Specify any special markings or identification.

NOTE: When ordering spare parts, please give valve serial numbers when available. For part numbers, refer to data sheets, which are available on request.

Warnings

1. The inside diameter (ID) of inlet piping (and block valve, if installed) MUST equal or exceed the ID of the relief valve inlet. Any flow restriction in the inlet piping or block valve can cause malfunctioning of the relief valve and will adversely affect the relieving capacity. Block valve should be locked in the OPEN position.
2. Risers longer than three pipe diameters should be at least one pipe size larger than the relief valve.
3. Exhaust (outlet) must be directed away from any area that may be occupied and away from any nearby structures. Vertical exhaust is preferred.
4. Valve must be properly supported to withstand the reactive thrust created by the exhaust flow when the exhaust is vented to atmosphere, especially for side discharge valves.
5. Valves installed on long risers or with any restrictions in the inlet piping or any valve being used on liquid service should be installed with a remote sensing line. Introduce sensing pressure as slow as possible to pilot to ensure piston dome is completely charged.
6. Care should be taken not to install a valve in a piping system that has the same natural frequency as the valve. Riser length should be kept to a minimum to avoid major vibration problems. Contact NuFlo Measurement Systems for assistance.



NuFlo Measurement Systems

A NuFlo Technologies Company

North America: 1.800.654.3760 nuflotech@nuflotech.com	Singapore: 65.6737.0444 singapore@nuflotech.com	Bognor Regis, UK: 44.1243.826741 uk@nuflotech.com
--	--	--

USA: Houston, TX • Corpus Christi, TX • Longview, TX • Odessa, TX • Duncan, OK
Shreveport, LA • Houma, LA • Lafayette, LA • Laurel, MS • Bakersfield, CA
Saginaw, MI • Casper, WY • Broomfield, CO • Dallas, TX • Tulsa, OK

Canada: Calgary, AB • Edmonton, AB

International: Jakarta, Indonesia • Aberdeen, Scotland • Bognor Regis, UK
Dubai, UAE • Hassi Messaoud, Algeria • Singapore

www.nuflotech.com • HOUSTON HEAD OFFICE: 281.582.9500

For representation in your area: